

Special Notes on installing a Ceiling Panel

The ceiling structure must be sound.
Minimum ½" sheetrock fastened at least every
8" with screws to joists/beams above.

TERE-STONE® ceiling panel must be supported mechanically on all 4 edges as well as being bonded to the ceiling sheetrock with Silicone RTV Adhesive. Apply a heavy 3/8" bead spaced 3" in from all edges and in a zig zag pattern across the center maintaining a spacing of 8" between beads.

Figure that a 36" x 60" panel will require two
10 oz. tubes of silicone.

In a typical installation, install the Ceiling Panel first, before the Side and Back Wall Panels.